

ZOUKEI-MURA INC.

@ZOUKEI-MURA INC. All rights recorded






http://www.zoukeimura.co.jp/ Plan & Design: Zoukei-Mura, Inc. Distributor: VOLKS, Inc. 60 Goshonouchi Nakamachi Shichi-jo

Shimogyo-ku, Kyoto Japan 600-8862

- ■Please carefully read the assembly manual prior to opening and make sure that everything is included. Please refer to the 1/32 \*Ta 152 H-1\* kit's Instruction Manual too when using this set.
- ■To use this item, tools such as a pin vise and a 2.2mm diameter drill bit are required (refer to page 5 of the kit's Instruction Manual). Please prepare them.
- ■Please replace the MGI51 barrel, pitot tube and antenna parts of the 1/32 "Ta 152 H-1" with this kit. In case the diameter of the gun barrel does not fit the hole of the kit's part, please open a hole with a pin vise and a 2.2mm diameter drill bit to insert the qun barrel.
- During assembly, adjust the orientation of each part while checking the balance and pose of the entire kit.
- ■Instant glue should be used for these parts. Please note that they cannot be glued with plastic model kit cement. Before painting, please make a base coat of metal primer (otherwise, the paint will chip off as time passes).
- ■The recommended brand for painting your kit is the latest line of paints from Vallejo Color, due to its non-toxicity and environmental friendliness. While referring to resources on historical Luftwaffe aircrafts, you may paint the model with the coloring of your choice.
- \*\*When it comes time to use tools and paints, please carefully follow each tool instructions for your safety.



We take the utmost of care when overseeing manufacturing, but if your kit is among the very small percentage that contains a defective part, please contact customer service within two weeks of your purchase with your full name and order number.

Purchasers from VOLKS Japan International Web Site: Please contact imos@volks.co.jp. Purchasers from VOLKS USA: Please contact service@volksusa.com.

## Turned Metal Machine Gun and Pitot Please refer to the Instruction Manual of the **Tube Assembly Instructions** 1/32 "Ta 152 H-1" to assemble this set with the kit. 1/32 Ta 152 H-1 🚃 🚃 Instruction D Attach first the fairings to the MG151 gun barrels, then attach the barrels to the wings. In case the wings' C-38 Wing Spar holes for assembly are not opened please use a pin vise and a 2.2mm diameter drill bit to open them. Attach Attach instead of instead ofpart B-17 **○Fairings Attachment to the MG151 Gun Barrels** Use the parts after attaching the 2 fairings as shown. Please assemble 2 sets ■MG151 Gun Barrel ■Fairing B ■Fairing A

