



1/48 F-4 C/D
Instruction Manual p6.



004

Console

For C Type Assembly ← ? → For D Type Assembly



For C Type Assembly ← ? → For D Type Assembly





1/48 F-4 C/D
Instruction Manual p7.

005

Back Seat Instrument Panel

For C Type Assembly ← ? → For D Type Assembly




1/48 F-4 C/D
Instruction Manual p7.


006

Fuselage Outer Panel (Right)

Common to C/D Types



Remove the plastic according to the shapes of the turned metal parts.




1/48 F-4 C/D
Instruction Manual p8.


007

Fuselage Outer Panel (Left)

Verify that the parts fit perfectly and attach.



Common to C/D Types




1/48 F-4 C/D
Instruction Manual p26.

038

Canopy

Common to C/D Types



For C Type Assembly ← ? → For D Type Assembly

