




## 3-4. Engine Equipping



### Engine Cowling

Warning Note When Assembling Do Not Glue



Be careful not to glue the engine cowling and the movable axis!!

Position for gluing parts:  
rear view



## 3-4. Engine Equipping Completed

