






3-4. Engine Equipping

Equipping the Engine


 Warning Note When Assembling




Position for gluing parts




Position for gluing parts:
top view



Position for gluing parts:
side view

 Fix it firmly to the main frame through the engine mount.

Front








Top


Front

3-4. Engine Equipping

Oil Cooler + Side Panels

 Paint Number  Warning Note When Assembling



③  Attach the side panels to the oil cooler.

