


Refer to the A-1H1s manual

# p28.


## How to Assemble the Nose Fairing



Refer to the A-1H1s manual

# p11.


## How To Assemble the Carburetor Air Scoop



## How to Assemble the Cowl Flaps in the Open Position


23 (18, 19, 20, 21, 22)

Assemble all six parts in the same way.



A

Attach the photo-etched parts before attaching the parts to the aircraft.



## How to Assemble the Cowling, Etc.

1a, 34

33

