3-7. Start Assembling Each Wing and the Final Outfitting

Front Wings / Side Wings / Cowl Flaps

Option: Assembly Option
! Warning Note When Assembling

① Right Front Wing

② Right Side Wing / Left Side Wing

③

④

Position for attaching parts

! Attach the left and right forward wings inside the nose.

! You can choose whether to attach the cowl flap in an open or closed state.

Position for attaching parts

3-7. Wings and Final Outfitting

Aileron

Option: Assembly Option
! Warning Note When Assembling

① Left Aileron / Right Aileron

Position for gluing parts

② Left Aileron / Right Aileron / F-14 Leg Rest / F-15 Leg Rest

Flaps

① ! You can choose whether to attach the flaps in a raised or lowered state.

Raised State Remove part of the projection by modifying it.

Lowered State Use it as it is without altering it.

Position for gluing parts

② Flaps in Raised State / Flaps in Lowered State

! Be careful: if you modify you can't use them in their lowered state!!

Flap Attachment Cross-Section View
Main Wing
Flap
Attach this part horizontally.